

ASSEMBLY INSTRUCTIONS FOR RADIALLY-ASSEMBLED RETAINING RINGS DIN 6799

Retaining Rings type DIN 6799 can be assembled by simply pushing the ring into the groove on the shaft. For a faster and easier installation, retaining rings DIN 6799 can be supplied stacked on steel rods and can be mounted using the appropriate Applicator and Dispenser.



GUIDELINES FOR USE OF APPLICATOR AND DISPENSER FOR RETAINING RINGS DIN 6799

1. Remove the locking of the loader.
2. Insert the tapered end of the loader into the slot of the dispenser, making sure that the tapered part makes contact with the bottom. Lock it in with the knurled screw. (The open side of the rings must face the opposite side to the locking screw).
3. Insert the applicator (with the number printed upwards) into the dispenser guides and push it to the stop position.
4. Remove the applicator. A ring will remain inserted in the special elastic housing and can be easily assembled

